

This document describes the process used to assemble a Right of Way Monumentation Sheet. An InRoads XML report is used to display the required data from the geometry project. This data is copied and pasted into the JPC#Monumentation.xls Excel file and then linked to the MicroStation JPC#ROWMonumentationSheet##.dgn file.

Creating the InRoads XML File

The data used to create the Right of Way Monumentation sheet is stored in an InRoads Geometry Project (*.alg). Depending on the data required, one of two different reports are used to extract the data from the geometry project. Both reports display Point Number, Northing, Easting, and Elevation. If this is all the data that is required, a Geometry report is used. If Station and Offset information is also required, then the Clearance report is used.


Geometry Report

Aside from having the data in the geometry project, there are no other prerequisites for creating a Geometry report.


1. From the InRoads dialog box, select **Tools > XML Reports**. The **XML Reports** dialog box is displayed.



- 2. Select the **Geometry** tab at the top of the **XML Reports** dialog box.
- 3. In the **COGO Points** area, use the **Include** field to key in the desired COGO point numbers then Tab to accept the key in. These can be specified as a range (*XXX-XXX*), a list of individual points (*XXX,XXX,XXX*) or a combination of both (*XXX-XXX,XXX-XXX*). If the required point numbers are not known, all of the points can be listed by using the asterisk (*). The asterisk can be used in conjunction with text to limit the list of points. For example, keying in '10*' would find all points whose first two digits were'1' and '0'.
- 4. Select the **Save** icon to compile the report. This displays the **Export** dialog box.



- 5. In the **Export** dialog box's **File Name** field, key in the desired file name.
- 6. Select the **Save** icon to complete the report.



This will dismiss the Export dialog box and display the **Bentley InRoads Report Browser**. This will be discussed later in the workflow.


Clearance Report

This report is used to generate station and offset information. In order to calculate this information, a horizontal alignment must be present.

- 7. From the InRoads dialog box, select **Tools > XML Reports** as shown above. Select the **Clearance** tab at the top of the dialog box.
- 8. In the **From** area, select the **Horizontal Alignment** toggle.
- 9. Use the drop-down to select the desired horizontal alignment. This is the alignment from which the station and offset is measured.
- 10. In the **COGO Points** area's **Include** field, key in the desired COGO point numbers then Tab to accept the key in (see 3 above for key in options).
- 11. Select the Save icon to compile the report.



- 12. This displays the **Export** dialog box. In the **File Name** field, key in the desired file name.
- 13. Select the **Save** icon to complete the report.



This will dismiss the Export dialog box and display the **Bentley InRoads Report Browser**.


The Bentley InRoads Report Browser

The Bentley InRoads Report Browser is a modified version of the Internet Explorer web browser used specifically for InRoads XML reports. It is launched automatically when an XML report is saved. It can also be launched by selecting **Tools > View XML Reports** from the InRoads dialog box. The illustrations below will be using the List Coordinates report, however procedures are the same for the Clearance report.

Selecting an XML Report Template

Report templates are program files that format the raw data contained within the XML file. When the Bentley InRoads Report Browser opens, it selects a default report template for the type of report that was created.

14. CDOT's custom report templates are stored in the CDOT folder. Data on the CDOT folder to display the templates. Two custom templates are provided for creating Monumentation sheets; CDOT_Monumentation_ListCoordinates and CDOT_Monumentation_Clearance. Data on desired the template name to activate that template.




This updates the report layout automatically.



Format Options

The default precision is set for two decimal places. If a different precision is required, it can be set using **Format Options**.

- 15. From the Bentley InRoads Report Browser, select **Tools > Format Options**. This displays the dialog box.
- 16. Use the pull downs to set the desired precision on the desired fields. For the reports discussed in this document, the following fields are used: Northing/Easting, Elevation, Linear (for offsets), and Station.




Selecting a different precision will automatically update the column or columns that use that format option. Select the Close icon to dismiss the dialog box when finished.

Copying The Report To The Monumentation Spreadsheet

Now that the report has been generated and formatted as desired, it can be copied into the JPC#Monumentation.xls Excel file. This file has separate sheets for different types of monuments. These are; ROW Markers To Be Set, Control Points TO BE Set, ROW Markers To Be Reset, Permenent Easement Markers, Aliquot Corners, and Temporary Easement Points. Because any number of these monument types may be stored in the geometry project, it may be necessary to copy different blocks of data from the report to paste into different sheets in the spreadsheet.


- 17. Open the JPC#Monumentation.xls file with Excel then minimize it.
- 18. Go back to the Bentley InRoads Report Browser and highlight the desired data in the report.
- 19. Right Click on the highlighted data to display the menu. Select **Copy** from that menu.




- 20. Minimize the Bentley InRoads Report Browser and maximize the Excel session.
- 21. Using the tabs at the bottom, select the sheet for the copied data.



22. Data in cell A3 of the selected sheet. This is where the copied data will be pasted. Right click in the same cell and select **Paste** from the menu that displays.




The illustration below shows the results of this operation.




Because the example is a List Coordinates report, the **Station** and **Offset** columns are empty. These two columns will be hidden in order to center the title over the data.


23. Select **Tools > Protection > Unprotect Sheet.** This will allow changes to be made to the sheets format so that the unused columns can be hidden.



- 24. Data and hold the mouse button on the 'F' column label and drag the cursor over the 'G' column label. Both columns highlight.
- 25. Right Click on the highlighted columns (in the body of the table) and select **Hide** from the menu.




26. The Station and Offset columns vanish and the title is centered over the remaining columns.




Before the sheet can be linked to the JPC#ROWMonumentationSheet##.dgn file, the gridlines need to be turned off. If they are left on, they will appear in a print of the dgn file.


- 27. Select **Tools > Protection > Protect Sheet** to maintain the new sheet formatting. This will display the **Protect Sheet** dialog box.
- 28. Toggle on **Protect worksheet and contents of locked cells**, **Select locked cells**, and **Select unlocked cells**. Select the **OK** icon to accept the changes and dismiss the dialog box.



29. Select **Tools > Options** from the Excel menu.




- 30. From the **Options** dialog box, select the **View** tab.
- 31. In the **Windows Options** area, toggle off **Gridlines**. Select the **OK** icon to accept the changes and dismiss the dialog box.




The left most column in the JPC#ROWMonumentationSheet##.dgn file can hold 50 rows of data (not counting the two title rows). Other columns can hold 41 rows of data. If there are more rows of data than a column can hold, the sheet can be copied and the duplicate data deleted from the sheets.

32. To make a copy of a sheet, right click on the sheet tab (at the bottom of the window) and select **MOVE or Copy** from the menu.



33. In the **Move or Copy** dialog box, toggle on **Create a copy**. Select the OK icon to create the copy and dismiss the dialog box.




- 34. The Copy is denoted with (2) appended to the sheet name. The sheets can be renamed by right clicking on the tab and selecting **Rename** from the menu. Key in the new name and press the enter key to accept the change.
- 35. In the original sheet, delete all the data below row 52 for the long column 43 for the short columns (the long column can hold 50 rows of data and there are two rows of headings).
- 36. In the copied sheet, delete the data from rows 3 through 52.

Linking the Spreadsheet to the MicroStation Sheet File

Once the data has been copied to the spreadsheet and the sheets formatted, they can be linked to the MicroStation sheet border.


- 37. Open the JPC#ROWMonumentationSheet##.dgn file with MicroStation then minimize it.
- 38. In The Excel file, highlight the data to be linked. Be sure to include only columns and rows with data (including the two title rows).
- 39. From the Excel menu, select **Edit > Copy** (or right click in the highlighted area and select **Copy** from the menu).




40. Maximize the MicroStation window. From the menu select **Edit > Paste Special**.



41. The **Paste Special** dialog box is displayed. Select **Linked MicroSoft Office Excel Worksheet** from the list and **Data** the Paste icon.




- 42. In the **Paste OLE** tool settings box, set the **Method** to **By Size**.
- 43. In the **Scale** field, key in **9**.



An outline of the linked file is attached to the cursor.


44. Move the outline near the corner of the no-plot column markers and **Data** to place the file.

45. Zoom in around the corner of the no-plot column marker. Select the **Move** command and **Tentative** to the corner of the linked file and accept. Then **Tentative** to the corner of the column marker, **Data** to accept and move the linked file, then **Reset** to release the file.



This will place the linked file in the correct location within the sheet border. Repeat this process with the other sheets in the spreadsheet as needed. It may be necessary to make copies of the JPC#ROWMonumentationSheet##.dgn file to hold all of the data.

Below is an example of a finished sheet.



Linking a Spreadsheet with the Station and Offset Columns

Because spreadsheets with the Station and Offset columns displayed are wider, only two sets of data can be displayed on a single sheet. This will require some minor modification to the JPC#ROWMonumentationSheet##.dgn file. The three column boxes inside the sheet border will be replaced by two, larger column markers.


- 46. Delete the three column boxes from inside the sheet border.
- 47. Select the **Fit View** icon to display the contents of the entire file. The two larger column boxes will appear the left of the sheet border.
- 48. <u>Select the **Element Selector** tool and highlight both boxes.</u>




49. Select the **Move** icon and **Data** near one of the highlighted boxes.



50. In the **Key In** dialog box, type "*di=12,0*" and press the **Enter** key. This will move the column boxes into place. **Reset** to exit the Move command then **Data** to unhighlight the boxes.



Below is an example on the results of this procedure.



51. Follow steps 37 through 45 above to link the spreadsheets to the sheet border file.